

CABLE CARRIERS

- These cable carriers can be opened : the inner cross bars are clipped in place.
To open them, slide a flat-head screwdriver under the edge at the cross bar's tip
- To facilitate installing the cables with connector, unclip the end link to place the cable carrier flat.
- If several series of cables are to be passed through the cable carrier, separators are individually supplied to prevent the cables from criss-crossing.
These separators are clipped to the cross bars (distribute the separators evenly over the entire cable carrier length)

